ADVANCE ADAPTERS INC.

P/N: 27-0012T

P.O. Box 247, 4320 Aerotech Center Way Paso Robles, CA 93447 Telephone: (800) 350-2223 Fax: (805) 238-4201

PAGE 1 OF 1 Page Rev. Date: 11-30-10

AMC 4.0L &4.2L TRANNY KIT NV4500/ NEW BELLHOUSING KIT

KIT CONSISTS OF:

No.	Qty	Part No.	Description
1.	1 Kit	50-0204	NV4500 TO NP231 WRANGLER 29T KIT
2.	1 Kit	50-0231	29 SPLINE NP231 INPUT GEAR
3.	1 Kit	712568	NV4500-1996GMTRANS/AMCENGINEBHSG.
4.	1 Kit	716008	WRANGLER CROSSMEMBER MOUNT
5.	1 Kit	716050D1	NV4500 SHIFT HANDLE ASSY.
6.	1	716130H	SLAVE CYLINDER HOSE
7.	1 Kit	716331	*JEEPSLAVECYL.KIT
8.	1	716130F	SLAVE CYLINDER FITTING

INSTALLATION NOTES:

This kit is designed to fit the 29 spline Dodge Standard Duty NV4500 transmission.

This kit must also have a new input shaft 52-0221 or you should be using our transmission P/N 26-0029GM

This is a parts pull sheet. Refer to the instruction sheet on each kit for proper installation.

SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.