## ADVANCE ADAPTERS INC.

*P/N: 716048* 

P.O. Box 247, 4320 Aerotech Center Way
Paso Robles, CA 93447
Telephone: (800) 350-2223 Fax: (805) 238-4201

PAGE 1 OF 1 Page Rev. Date: 10-29-01

## DANA 300 CROSSMEMBER SPACER

## **KIT CONSISTS OF:**

| <u>No.</u> | Qty | <u>Part No.</u> | <b>Description</b>          |
|------------|-----|-----------------|-----------------------------|
| 1.         | 1   | 716048-BLK      | DANA 300 CROSSMEMBER SPACER |
| 2.         | 2   | 724301          | NYLONLOCKNUT                |
| 3.         | 4   | 724302          | FLAT WASHER 7/16" SAE PLT.  |
| 4.         | 2   | 724307          | H.H.C.S. 7/16"-14 X 1"      |

## **INSTALLATION PROCEDURES:**

This spacer works with the 716021 crossmember mount by bolting the 716048-BLK to the adapter housing. This will step the mounting area down so the 716021 is far enough down to reach the skid pan of the Jeep.



SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.